


ZEPHYR

PRPNLC24AKIT

Presrv™ Solid Panel Ready Door Kit, Compact



1. Solid Panel Ready Door



2. Upper Hinge Connecting Plate, Right




3. Connecting Plate Screws, M4*12



4. Lower Hinge Connecting Plate, Right



5. Connecting Plate Screws, M4*12



6. Door Gasket



7. Door Magnet



8. Door Magnet Bracket




9. Screw, ST3*8



10. Door Lock Plate



11. Screw, M4*8




12. Self Tapping Screws, ST4*30



13. Door Handle Screw, M4*40



14. Washer (4.3ID, 8OD)



15. Upper Hinge, Left




16. Upper Hinge, Right




17. Screw, M4*12



18. Lower Hinge, Right



19. Lower Hinge, Left



20. Lower Hinge Screw, M5*12



21. Upper Hinge Connecting Plate, Left



22. Lower Hinge Connecting Plate, Left



23. Connecting Plate Screws, M4*12




24. Upper Hinge Top Screw



25. Door Axis Plate



26. Door Axis Plate Screw



27-1. Kick Plate



27-2. Door Switch



27-3. Door Lock



28. Kick Plate Screws, ST4*8

PRPNLC24AKIT

Ref #	Part #	Description	Qty.
1	50230044	Solid Panel Ready Door	1
2	54190080	Upper Hinge Connecting Plate, Right	1
3	01020026	Connecting Plate Screw, M4*12	2
4	54190081	Lower Hinge Connecting Plate, Right	1
5	01020026	Connecting Plate Screw, M4*12	2
6	56220061	Door Gasket	1
7	54220011	Door Magnet	1
8	54140366	Door Magnet Bracket	1
9	01020044	Door Magnet Screw, ST3*8	2
10	54050095	Door Lock Plate	1
11	01020097	Door Lock Plate Screw, M4*8	2
12	01020055	Self Tapping Screws, ST4*30	10
13	01020054	Door Handle Screw, M4*40	2
14	02170014	Washer, (4.3ID, 8OD)	2
15	54180039	Upper Hinge, Left	1
16	54180036	Upper Hinge, Right	1
17	01020026	Upper Hinge Screw, M4*12	6
18	54180037	Lower Hinge, Right	1
19	54180038	Lower Hinge, Left	1
20	01020052	Lower Hinge Screw, M5*12	6
21	54190065	Upper Left Hinge Connecting Plate	1
22	54190066	Lower Left Hinge Connecting Plate	1
23	01020026	Hinge Connecting Plate Screw, M4*12	4
24	01020042	Upper Hinge Top Screw	2
25	54190079	Door Axis Plate	1
26	01020082	Door Axis Plate Screw, M5*8	2
27-1	50260019	Kick Plate	1
27-2	11040033	Door Switch	1

27-3	50180010	Door Lock	1
28	01020073	Kick Plate Screw, ST4*8	5
29	02170017	Washer, (10.5ID, 17OD)	1
30	02170018	Washer, (8.5ID, 17OD)	1
31	54140381	Anti Tip Bracket, Right	1
32	54140382	Anti Tip Bracket, Left	1
33	01020094	Screw, M4*12	2
34	01020079	Screw, ST4*12	2

MAR24.0101